Chapter 1 Bio-optoelectronic Measurements 光電生醫量測技術

王安邦

Prof. Dr.-Ing An-Bang Wang

Institute of Applied Mechanics National Taiwan University TEL: 886-2-3366-5067 E-mail: abwang@spring.iam.ntu.edu.tw

By An-Bang Wang

Bio-optoelectric Measurements



Lecture Contents


Date	課程名稱	週數	授課教師
2/22	光電生醫量測簡介	1	王安邦
3/1; 3/8; 3/15; 3/22	紅外線溫度量測理論與實習	4	楊丙?
3/29*	紅外線生醫影像應用與診斷	1	楊永健
4/11; 4/18; 4/25*	核磁共振掃描技術、應用及	3	曾文毅
(Mon.)	其發展		
5/3	光電速度與粒徑量測理論	1	王安邦
5/10	光電速度量測之生醫應用	1	余幸司
5/17	內視鏡原理應用與未來發展	1	谢銘鉤
5/24	雷射光電技術於眼科之量	1	尤之浩
	測、診斷、應用與未來發展		
5/31; 6/7; 6/14	奈米光電生醫量測原理、應	3	林世明
	用與未來發展:		
	(1) 原子力顯微術、掃描穿隧顯微		
	術、近場光學顯微術:生物奈		
	米量測與奈米診斷。(2) 光學生物晶片與生物感測		
	器:生物分子間相互作用動力		
	學與量論。		
	(3) 雙極性干涉術:蛋白構形形變		
	奈 米 量 測 。		
6/21	期末報告	1	王安邦/林世明

* 18:30 ~ 21:15

Bio-optoelectric Measurements

By An-Bang Wang


Tools for Solving Problems in Engineering



Bio-optoelectric Measurements



Experiments & Simulations in Engineering



Bio-optoelectric Measurements

By An-Bang Wang


From Pure Engineering to Bio-optoelectronic measurements

- Life is invaluable
- Life is environmental-conditiondependent
- Life is time-dependent
- The bio-medical measurements are much more complicated ...
- More interactions between engineering and medical colleges are needed

Bio-optoelectric Measurements



Trend of the world



What is Temperature?

Qualitative Definitions:

- 1. The degree of hotness or coldness of a body.
- 2. All bodies have the same temperature if they are in thermal equilibrium.
- 3. The level of thermal energy. (cf. Electrical energy; Mechanical potential energy.)

□ Units of temperature (one of System International units, SI) :

Unit		Symbol	Quantity measured
	1. Meter	m	Length
Dimensional	2. Kilogram	kg	Mass
	3. Second	S	Time
	4. Ampere	А	Electric current
	5. Kelvin	K	Temperature
	6. Mole	mol	Amount of substance
	7. Candela	cd	Luminous intensity
Dimensionless	8. Radian	rad	Plane angle
	9. Steradian	sr	Solid angle

(from Lee (2001))


Bio-optoelectric Measurements

By An-Bang Wang

How to Quantify the temperature?

□ Four common temperature scales:

Fahrenheit(1708), Celsius(1740), Kelvin(1848), Rankine(1730)



□ Fundamental temperature scales:

The relationship of measured variable to temperature depends only on fundamental physical constants, not on arbitrary calibrating constants.

Examples:

1. Thermodynamic, $PV=PV(T, \underline{N}_A, \underline{k})$

2.Thermal radiance, W=W(T, k, c, h)

(from Lee (2001))

光機電工程教學資源中心


Bio-optoelectric Measurements

By An-Bang Wang

Opto-Mechatronics Education Resources Center

Body temperature & it's control

- Core temperature and skin temperature
- Core temperature remains almost constant 98~98.6±1°F, (36.7~37±0.6°C) except illness.




Bio-optoelectric Measurements

By An-Bang Wang

Opto-Mechatronics Education Resources Center

Body temperature & it's control

- Temperature measurement depends on position (rectal ~ oral + 0.6°C), exercise and surrounding conditions.
- Body temp. is controlled by balancing heat production against heat loss
- Most heat of body is produced from liver, brain, heart (and skeletal muscles during exercise) and lost through skin to the air.



Bio-optoelectric Measurements

By An-Bang Wang

Heat production & lose

- Heat production is main by-product of metabolism
- Metabolic rate of body is influenced by
 - basal metabolism of all cells of body
 - extra metabolism of muscle activity
 - extra metabolism by thyroxine (甲狀腺素), epinephrine(腎上腺素), norepinephrine (正腎上腺素), sympathetic stimulation on the cells.
 - extra metabolism by increased chemical activity in cells




Thermal Insulation of body

- The fat of subcutaneous tissues, conduct heat only 1/3 as other tissues, act as the main heat insulator of body.
- Heat loss decreases ~50% for usual suit of clothes. About 50% heat transmitted from skin to the clothing by radiation. Insulating property could increase by Au-coating inside of clothing
- Blood flow from the body core to the skin, the effective *heat radiator*, provides heat transfer of the body
- Heat transfer to skin by blood is controlled by sympathetic nervous system

Bio-optoelectric Measurements

By An-Bang Wang




Opto-Mechatronics Education Resources Center

光機電工程教學資源中心

How does heat loss from skin ?

- Body heat is lost by radiation, conduction and evaporation
- Radiation of a nude person in room at T_{room} is ~60% total heat
 Conduction to air (Air currents (convection loss. Wave length of radiation: 5 ~ 20 μm.




- About 15% of total heat loss is conducted to the air. The cooling effect of wind (at low wind velocity) is proportional to (wind velocity)^{0.5}
- Evaporation heat of water: 0.58 kcal/g. Water is insensibly evaporated from skin and lungs (without sweating) at a rate of 450~600 ml/day (12 ~ 16 Kcal/hr). Evaporation is necessary cooling mechanism at very high air temperature.

Bio-optoelectric Measurements



Skin temperature v.s. Core temperature

Thermostatic detection of temperature in the Hypothalamus (下視丘)




Measurements

By An-Bang Wang

Opto-Mechatronics Education Resources Center

Abnormality of temperature regulation

Fever means body temperature above the normal range that can be caused by abnormalities in the brain itself or by toxic substances that affect the temperature regulation system. They include bacterial diseases, brain tumors, ... etc.



Bio-optoelectric Measurements

By An-Bang Wang

Opto-Mechatronics Education Resources Center


光機電工程教學資源中心

Classification of Temperature Sensors


	Principle							
Sensor	Thermo- electric	Electrical Resistance	Carrier Mobility	Thermal Radiation	Electrical Capacitance	Thermal Expansion	Resonant Frequency	Others
Thermocouple								
Thermopile								
RTD(PTC, NTC)								
Thermistor								
P-N junction								
Optical pyrometer								
Pyro-electric								
Quantum								
Spectroradiometer								
Cooling IR imager								
Uncooled IR imager								
Gas								
Liquid								
Bi-metal								
Quartz								
Liquid Crystal								1
Others								2,3,4,5

(from Lee (2001))

Bio-optoelectric Measurements



Analysis of common temperature sensors



Measurements


By An-Bang Wang

Opto-Mechatronics Education Resources Center

Liquid crystal Thermometer


Forehead Thermometer Fish box thermometer

- Safe
- convenient
- accurate
- Time constant: some seconds
- Mirror or observer is needed.




From: Taiwah Charts Corp.

Bio-optoelectric Measurements



IR measurement

- All bodies radiate Infrared wave
- Infrared measurement technology is counted among the key applications in the medical field.
- Thermal examinations of the human body have no harmful effects.



www.vega.org.uk/. ../index.php

 One of the main applications is the early diagnosis of tumors and skin cancer. A classical use of thermal imaging systems is the detection of disturbances in the venous blood circulation and the early diagnosis of thrombosis and strictures of vessels.


Bio-optoelectric Measurements



Thermography

Thermography also holds a firm place with transplantations of organs especially of the heart. While implanting the organ the acceptance and the blood circulation can be monitored online and exactly determined. New experiences open up in

the surveillance of laser based ablations (i. e. with ophthalmology).




(www.livengood-lifestyles.com)

Bio-optoelectric Measurements


By An-Bang Wang

The Electromagnetic Spectrum



Opto-Mechatronics Education Resources Center

Infrared Imager




Bio-optoelectric Measurements

By An-Bang Wang

Visible cf. Thermal Radiation (1)

□ Target signature (Spatial Distribution)



Visible(0.4-0.75µm)

FIR(8-12µm)

FIR(8-12µm)

- Active sensing : Visible, NIR
- Passive Sensing : Visible, NIR, MIR, FIR


(from Lee (2001))

Bio-optoelectric Measurements

By An-Bang Wang

Visible cf. Thermal Radiation(2)

Background signature (Spatial Distribution)




Ref. "Thermal imaging solutions", TI NIGHTSIGHT interactive explorer.

(from Lee (2001))

Bio-optoelectric Measurements

By An-Bang Wang



核磁共振掃瞄儀 (Magnetic Resonance Imaging, MRI)



(From莊凱翔)

Bio-optoelectric Measurements

By An-Bang Wang





(From: minho.show.org.tw)

Bio-optoelectric Measurements


By An-Bang Wang

膠囊內視鏡,約11x26釐米大小 ,內含前端攝影機、影像感應 傳送器和精密電池(八小時的電 池待命期)。現有的小腸鏡僅能 檢查小腸的前三分之一段,檢 出率僅三成,而血管攝影與核 醫檢查則必須在病灶出血時才 能檢出,相較之下,膠囊內視 鏡更容易檢出小腸病灶,檢出 率約六至七成。限制性,它無 法向胃鏡般重覆觀看同一部位, 且無法切片,所以有時較難判 斷。

Opto-Mechatronics Education Resources Center

光機電工程教學資源中心

眼科光電技術



Bio-optoelectric Measurements



Imaging and Display technology

Picture Archiving and Communication System, (PACS)

醫療影像擷取儲存傳輸系統






Bio-optoelectric Measurements

By An-Bang Wang


Holographic See-through Browser



Bio-optoelectric Measurements

By An-Bang Wang

Surface Plasmon Resonance (SPR)




By An-Bang Wang Opto-Mecha

Measurements

Opto-Mechatronics Education Resources Center

Dual Polarization Interferometry (I)




Measurements

By An-Bang Wang

Opto-Mechatronics Education Resources Center

Dual Polarization Interferometry (II)



Optical Velocity measurement




(From Y.H. Shau)

Bio-optoelectric Measurements

By An-Bang Wang

Pulsed Doppler Ultrasonic technique

• Pulsed Doppler Ultrasonic technique



History of Physiological Fluid Dynamics I

- Fluid: a substance which moves continuously under the action of shearing forces, no matter how small that shearing force may be. (i.e. Liquid or Gas).
- Leonardo da Vinci (1452-1519)
 - scientific approach to human anatomy
 - illustration of the cardiovascular system
 - remark on the thickening and hardening of arterial walls with age (Atherosclerosis)
- William Harvey (1578-1658)
 - Circulation of Blood flow
- Stephen Hales (1677-1761)

– Measurement of blood pressure, arterial dimension, Blood Flow velocity

Bio-optoelectric Measurements

By An-Bang Wang


(From Y.H. Shau)



History of Physiological Fluid Dynamics II

- Stephen Hales (1677-1761)
 - Measurement of blood pressure, arterial dimension, Blood Flow velocity
- Leonhard Euler (1775)
 - One-dimensional inviscid incompressible flow in an elastic tube.
- Thomas Young (1808)
 - propagation of sound through an elastic solid or compressible fluid
- Poiseuille (1840)
 - Viscous pressure drop in blood vessels
- Otto Frank (1898)
 - Theory of wave propagation in the circulatory system (From Y.H. Shau)

Bio-optoelectric Measurements



History of Physiological Fluid Dynamics III

- Fahraeus and Lindqvist (1931)
 - apparent viscosity of blood decreases as the tube diameter decreases
- McDonald and Womersley (1950)
 - Modern linear theory of wave propagation in the circulatory system
- Lambert (1958)
 - Nonlinear theory of wave propagation and Fluid flow in non-rigid tube
- Pedley (1980)
 - Fluid mechanics of large blood vessels


(From Y.H. Shau)

光機電工程教學資源中心

Opto-Mechatronics Education Resources Center

Bio-optoelectric Measurements

Hydrostatics of circulation




Bio-optoelectric Measurements

By An-Bang Wang

必 光機電工程教學資源中心 Opto-Mechatronics Education Resources Center

Pressure and Flow Pulse




Bio-optoelectric Measurements

By An-Bang Wang

必 光機電工程教學資源中心 Opto-Mechatronics Education Resources Center

Velocity and pressure of blood flow




Bio-optoelectric Measurements

By An-Bang Wang

必 光機電工程教學資源中心 Opto-Mechatronics Education Resources Center

Ultrasound Flow measurement



(From Y.H. Shau)

Bio-optoelectric Measurements

By An-Bang Wang

☑ 光機電工程教學資源中心 Opto-Mechatronics Education Resources Center

Terminology for Error Analysis


Terminology

- *Error*: deviation of the reading from a known input
- Accuracy: Error, usually expressed as a percentage of full-scale reading.for industrial or laboratory instruments.
- *Uncertainty*: range within the error is likely to fall with specified confidence limits (or fiducial limit).
- *Precision* (Repeatability):
 - *reproducibility* of the reading for a given input.
 - an instrument can be precise, but *not* calibrated or misused
 - accuracy of an instrument cannot be better than its precision.
- *Traceability*: The ability to trace the accuracy of a standard back to its ultimate source in the fundamental standards (e.g., NIST)
- Sensitivity : ratio of instrument output to input.

By An-Bang Wang

Bio-optoelectric Measurements *会* 光機電工程教學資源中心 Opto-Mechatronics Education Resources Center


Precision(repeatability) & Accuracy



Bio-optoelectric Measurements



Precision, Bias error & Accuracy (I)




Measurements

By An-Bang Wang

Opto-Mechatronics Education Resources Center

Precision, Bias error & Accuracy (II)



(From Miller, 1983)

With the outlier omitted, the average of the reading $\overline{I} = \frac{\sum I_i}{\sum I_i} = (210.1 + 210.0 + 209.8 + 210.2 + 209.9)/5 = 210.0$ the standard deviation is: $\sigma = \left[\frac{\sum (I_i - I) / I \right) \times 100\%}{1}\right]^{0.5}$ $= [(0.0023 + 0.0090 + 0.0090 + 0.0023)/(5-1)]^{0.5} = 0.0753\%$... the *precision* at the 95% confidence level is then: $\sigma_p = t_{st} \sigma$, where t_{st} is two-tailed student's t-value, could be found from table ($t_{st} = 2.776$ for n=5). : the precision is then $\sigma_p = 2.776 \times 0.0753\% = 0.21\%$ The *direction bias error* is $B = \frac{I - I_t}{I_t} \times 100\% = [(210 - 212)/(212)] \times 100\% = -0.94\%$ $\therefore \text{ the accuracy is } A_{cc} = B \pm \sqrt{(1 + \frac{1}{n})}\sigma_p = -0.7\% - 1.2\%$

Bio-optoelectric Measurements

By An-Bang Wang

Ø 光機電工程教學資源中心 Opto-Mechatronics Education Resources Center

Error Analysis

- Almost all bio-measurements are indirect.
- In experimental work, errors of two different types can occur:
 - Systematic Errors
 - poorly adjusted instruments
 - improper calibration
 - false instrument specification
 - incorrect or biased statistical estimators
 - Statistical or random errors
 - improper reading from a scale
 - statistical variance of the measured quantity.
- Some errors can be corrected or controlled, others (uncertainty) cannot. All must be estimated !


Bio-optoelectric Measurements

By An-Bang Wang




光機電工程教學資源中心

Some notes for electronics



Bio-optoelectric Measurements



Wheatstone bridge

The Wheatstone bridge is a basic building block of many measuring instruments. It allows precise measurement of minute change in resistance, capacitance or inductance. It has many applications in

- hot-wire anemometry
- strain gauges ____
- Inductive pressure transducers ____ or condenser microphones
- effective bridge resistance:


$$R_{eff} = \frac{(R_1 + R_4)(R_2 + R_3)}{R_1 + R_2 + R_3 + R_4} , E = E_b \frac{R_{eff}}{R_{eff}} + \frac{R_{eff}}{R_{eff$$

- Voltage measured at galvanometer:

$$E_{g} = \frac{E(\frac{R_{1}}{R_{1} + R_{4}} - \frac{R_{2}}{R_{2} + R_{3}})$$

Bio-optoelectric Measurements

By An-Bang Wang



光機電工程教學資源中心 **Opto-Mechatronics Education Resources Center**

References (I)

- Guyton, A. & Hall, J., Textbook of Medical Physiology, 10th Ed., A Harcourt Health Sciences Company, 2000.
- Benedict, R.P., Fundamentals of temperature, pressure and flow measurements, 3rd Ed., John Wiley & Sons, 1984.
- Lee, Tzong-Sheng, lecture note of *Thermal Measurement and Simulation of Optomechatronic Systems*, Temperature Measuring Technologies, - *Noncontact Methods*, 2001
- Bernard, R.D., Thermoelectricity in metals and alloys, Taylor & Francis, 1972
- Kinzie, P.A., Thermociouple Temperature Measurement, Wiley Interscience, 1973
- VKI lecture series, "Temperature measurements, 1996
- 林雲漢、陳吉良、王裕銘、王安邦、黃榮山、李世光、林世明 (2005)"雙偏極 化干涉術-生物分子奈米量測" 科儀新知 144, pp. 55-61

Bio-optoelectric Measurements



References (II)

- 邵耀華: Lecture notes for Physiological Fluid Dynamics, NTU-IAM, 2002
- **Biomechanics: Motion, Flow, Stress and Growth (text book) by Y.C.** ۲ Fung
- **Biomechanics: Circulation by Y.C. Fung**
- **Blood Flow through organs and tissues by Bain and Harper**
- The Fluid Mechanics of Large Blood Vessels by T. J. Pedley
- Cardiovascular Fluid Dynamics by Huang and Normann
- 王安邦等十六人合輯, 雷射熱流量測基礎訓練課程講義, NTU-IAM, Taipei, June 30 - July 11, 1997
- **Conference Proceedings and Journal Papers**
 - (Proceedings of Applications of Laser Techniques to Fluid Mechanics, Proceedings the International Symposium on Flow visualization,) 0t

Bio-optoelectric Measurements



